

Dolly Caster Assembly

WARNING: DO NOT OVERTIGHTEN !

1. Using the 5/16-18 inch nylock nuts provided with this Dolly, thread nut onto bolt by hand making sure the curved part of the nut is facing out.
2. Tighten slowly with a 1/2 inch wrench until there are only **1 or 2 threads showing past the top of the nut.**
3. **Do not over tighten!** 1 or 2 threads showing past the top of the nut is the torque specification for new Dollies.

